

Spray Paint Booths and Paint Mixing Rooms

Effective June 12, 2007

- Step 1** Plans are required.
- Step 2** Plans for fire suppression are required at time of submittal.
- Step 3** If the building has a fire alarm system the fire suppression system shall be connected.
- Step 4** Show floor plan of location of booth indicating:
 - a. Location and distance of all fuel-fired equipment from booth.
 - b. Tenant walls and their ratings.
 - c. Location of electrical equipment within 3' (all directions)
- Step 5** All elements of booth must be listed with manufacturers installation instructions provided at time of plan review.
- Step 6** The following permits will be required:
 - a. Fire Suppression for sprinklers
 - b. Fire alarm
 - c. Building
 - d. Mechanical/ Fire suppression for exhaust/vent (no license required)
 - e. Electrical
- Step 7** Building Code Summary required.